



ARRI TECHNICAL NOTE P-1012

Opening the 435 Movement August 1, 2000

Summary

This note describes why the 435 movement should not be opened while the camera is running.

**Don't open the 435 movement
until the camera has completely stopped!**

After the RUN button is pushed to stop the 435 from running, the camera will briefly run at 1 fps to place the mirror shutter in the correct viewing position. Under no circumstance should the movement be opened until it has come to a complete stop. Otherwise the movement could be damaged.

New EPROM

As a further precaution, all new EPROMs for the 435, starting with EPROM 1.34, will cut the power to the motor as soon as the movement is opened. For upgrade information, contact your local ARRI representative.

For more information on this issue, please contact your local ARRI representative.